



Scottoil: Yamaha TRX 850

Installation Guide for Yamaha TRX 850



Locate the vacuum – there is a vacuum pipe running from number 1 inlet manifold to the fuel tap. Also some models have a vacuum pipe running from No. 2 cylinder, which is blanked at the end.

Cut into one of these pipes and insert the T-Piece from the Scottoil kit.

Then press the Damper Elbow, part number 4, onto the third leg of the tee, as shown below left.



The RMV can be mounted under the seat as shown in the third picture.

The more vertical the RMV the better and remember to avoid exhaust and engine components.

For further information, see our easy step installation guide – **'RMV Positions, General'**.



The Dispenser Assembly, shown bottom left, is routed along the underside of the Swingarm using Dispenser Mounting Sleeves & Glue. **Note:** an epoxy resin (eg. Araldite) is req'd to bond the sleeves to the Swingarm.

For further information see our easy step installation guide - **'Dispenser Assemblies, General'**.

The nib should feed the sprocket between the 6 & 7 o'clock positions, with the cut face facing outwards,



Once fitted, fill and prime the system and set the adjuster knob to 'prime'.

Start the engine and turn the adjuster knob until a flow of between 1 and 2 drops per minute is achieved.

Check the condition of your chain after a ride, and then adjust as required.

If you have any further comments or queries, and are unable to resolve them using our website, please do not hesitate to call technical on 0141 955 1100 or email technical@scottoiler.com for assistance. Thank you.

Scottoil Ltd. 2 Riverside, Milngavie, Glasgow, G62 6PL Tel. 0141 955 1100 Fax. 0141 956 5896 www.scottoiler.com

